

Non-Vacuum a Central Vacuum

1. Remove Existing Pad
2. Remove **AVB0012** (Non-Vac Shroud)
Replace **AVB0012**
with **AVC0012** (5/6 in. SuperVac™ Shroud)



3. Install **AVA0205** (CV 3/4 in. Swivel Exhaust Assembly)
or **AVA0099** (CV 1 in. Swivel Exhaust Assembly)



4. Install **AVA0099/AVA0205** Using:

AVA0769 Screw
AVA0047 Washer
AVA0048 Nut



5. Attach Desired Pad:
1250110 5" Low Profile VAC Vinyl Pad
1250111 5" Low Profile VAC Hook Pad
1250310 5" Tapered Edge VAC Vinyl Pad
1250311 5" Tapered Edge VAC Hook Pad
OR
1260110 6" Low Profile VAC Vinyl Pad
1260111 6" Low Profile VAC Hook Pad
1260310 6" Tapered Edge VAC Vinyl Pad
1260311 6" Tapered Edge VAC Hook Pad

