

# Non-Vacuum a Self-Generate Vacuum

1. Remove Existing Pad
2. Remove **AVB0012** (Non-Vac Shroud)  
Replace **AVB0012**  
with **AVC0012** (5/6 in. SuperVac™ Shroud)



AVC0012

3. Install **AVA0006** (SVG Retainer), **AVA0044** (O-Ring) and **AVA0410** (1 in./28mm Hose SVG Swivel Exhaust)  
OR  
**AVA0409** (3/4 in./19mm Hose SVG Swivel Exhaust)



4. Install **AVC0108** (SuperVac SVG Exhaust Adapter)  
onto **AVC0012** (5/6 in. SuperVac Shroud)



AVC0108

Piece together as shown in image:



## Non-Vacuum a Self-Generate Vacuum

### 5. Install:

**AVA0412** (Airline with Ø 1 in. VAC Hose Bag Assembly)

If **AVA0410** is used

**AVA0411** (Airline with Ø 3/4 in. VAC Hose Bag Assembly)

If **AVA0409** is used



6. Attach **AVA0468** with **AVA0470** (Vacuum Double Bag)

### 7. Attach Desired Pad:

1250110 5" Low Profile VAC Vinyl Pad

1250111 5" Low Profile VAC Hook Pad

1250310 5" Tapered Edge VAC Vinyl Pad

1250311 5" Tapered Edge VAC Hook Pad

OR

1260110 6" Low Profile VAC Vinyl Pad

1260111 6" Low Profile VAC Hook Pad

1260310 6" Tapered Edge VAC Vinyl Pad

1260311 6" Tapered Edge VAC Hook Pad

